



Responsible Party:
PAX Technology, Inc.
8880 Freedom Crossing Trail
Building 400, 3rd Floor, Suite 300
Jacksonville, FL 32256, USA
Help Desk
1-877-859-0099
www.pax.us

Terminal Installation and Usage Tips

7

- 1) If any cables become damaged, seek a replacement.
- 2) Do not insert unknown materials into any port on the A80; this may cause serious damage.
- 3) If repairs are required, please contact a professional technician instead of attempting them on your own.
- 4) Avoid exposing the device to an excessively hot, dusty, or strong electromagnetic environment.
- 5) Do not vibrate, shake, or drop the device.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the body of this equipment is a label that contains, among other information, a product identifier. If requested, this number must be provided to the telephone company.

RF Exposure Information


This device meets the government's requirement for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

PAX Customer Support

For questions or help with the terminal installation please contact your service provider or PAX customer support.



A80 POS Terminal



Note: Product images shown may be different than actual product received

Contents Checklist

1

Please check the components after unpacking. If any are missing, or if there is a page missing from the product manual, etc., please contact the dealer.

Part	Qty
A80 Countertop Payment Terminal	1
AC Power Adapter	1
AC Power Cable	1
Telephone Cable	1
Thermal Paper Roll	1
Quick Setup Guide	1

Product Description

2




Figure 1. Front view

- 1) Printer Cover
- 2) Contactless Area & Printer Latch
- 3) Main Screen
- 4) MSR Reader
- 5) Power ON/OFF
- 6) EMV/Chip Reader




Figure 2. Back view

- 10) PIN Pad (Port)
- 11) RS232 (Port)
- 12) Serial Number
- 13) Nameplate
- 14) SD Card Slot
- 15) SAM Slots
- 16) Line (Port)
- 17) Phone (Port)
- 18) LAN (Port)
- 19) USB OTG (Port)

Instructions

3

The following sections cover basic operating instructions.

3.1 Power ON/OFF

POWER ON:

Press and hold the power button down for 3-5 seconds and then release.

POWER OFF:

Press and hold the power button down for 3 to 5 seconds and then release.

3.2 SAM/SD Card Installation




Figure 3. SAM and SD Card Slots

The A80 has two SAM card slots on the main body of the device and one SD card slot. These card slots are normally hidden under the back cover.

In order to install a SD or SAM card into any of these slots, insert a card into the card slot with the contacts facing upwards and the clipped corner of the card facing forward and to the right.

Card Readers

4

- **Magnetic Stripe Card:** Slide the card through the card reader slot from top to bottom or from bottom to top with the magnetic strip oriented towards the body of the device. Make sure that the card is fully inserted into the card reader while swiping the card.
- **Smart Card Reader:** Insert the card fully into the reader with the metallic contacts facing up and towards the device. Make sure that the card is fully inserted into the card reader while scanning the card.
- **Contactless Card Reader:** The contactless card reader reads cards and devices placed roughly within an inch (2.5 mm). For best results, place as close to the reader as possible and center the card over the indicated area.

Environment

5

- Working Environment** Temperature: -10°C ~ 50°C (14°F ~ 122°F)
Humidity: 10% ~ 93% (without condensation)
- Storage Environment** Temperature: -20°C ~ 70°C (-4°F ~ 158°F)
Humidity: 10% ~ 93% (without condensation)

Cleaning the Device

6

- Do not use industrial strength or abrasive cleaner as it may damage or scratch the screen.
- Do not immerse the device in water or liquid.
- Do not spray water or cleaner into EMV Card Reader or ports.
- To clean the screen, apply distilled water or mild glass cleaner onto a soft, lint-free cloth and gently wipe terminal.